



KASA Redberg

Engineers & Technical Trainers

Wind Loading to AS/NZS 1170.2

Online (e-Learning) Training Course



KASA Redberg

Engineers & Technical Trainers

KASA Redberg Pty Ltd ABN 35 107 585 375
PO Box 459, Balgowlah, NSW, 2093, Australia
Ph: +61 (0)2 9949 9795 Fax: +61 (2) 8246 6387
Web: www.kasa.com.au Email: info@kasa.com.au

Wind Loading to AS/NZS 1170.2

Course Synopsis

MODULE 1 – INTRODUCTION & BACKGROUND

- Brief History and Background
- Wind Forces
- Derivation of Design Wind Pressure
- The Scope of AS/NZS 1170.2
- Exclusions

MODULE 2 - SPEED

- Wind Speed Definitions
- Regional Wind Speed
- Site Wind Speed
- Wind Direction Multiplier
- Terrain/Height Multiplier
- Shielding Multiplier
- Assessing Terrain & Shielding
- Topographic Multiplier

MODULE 3 – DESIGN WIND PRESSURE

- Design Wind Pressures
- The Aerodynamic Shape Factor
- Openings
- Determining C_{fig}

MODULE 4 – VIDEO TUTORIAL

- Worked Example Problem – Freestanding Wall

MODULE 5 – VIDEO TUTORIAL

- Worked Example Problem – Rectangular Building

MODULE 6 – DOMINANT OPENINGS

- Wind Tunnel Simulation – Dominant Openings

MODULE 7 – FREE ROOFS

- Wind Tunnel Simulation – Free Roofs

MODULE 8 – DYNAMIC RESPONSE FACTOR

- Introduction to the Dynamic Response Factor
- Wind Sensitive Structures
- Rigidity and Serviceability
- Factors Affecting Natural Frequency
- Determining the Natural Frequency
- Calculating the Dynamic Response Factor

MODULE 9 – THETA AND WIND DIRECTION

- Theta and Wind Direction

MODULE 10 – FORCES

- AS/NZS 1170.2 Section 2.5
- Force Resultants

MODULE 11 – VIDEO TUTORIAL

- Worked Example Problem – Sewer Vent Stack

MODULE 12 – QUIZ

- End of Course Quiz

Example – Freestanding Wall

Given Data:

- Location: Adelaide
- R: 500
- Terrain: Terrain Category 3
- Shielding: No shielding
- Topography: Flat land on all sides
- Construction Type: Double brick
- Dynamic Response: $C_{fig} = 1.0$

Determining C_{fig}

- Curved Roof
- Multi-Span Roof
- Skewed Roof


Internal Pressures: $C_{fig} = C_{pe}, C_{pi}$

External Pressures: $C_{fig} = C_{pe}, C_{pi}, C_{pe}, C_{pi}$

For Functional Wind Forces: $C_{fig} = C_{pe}, C_{pi}$

Appendix C will also be required depending upon your building's roof profile or span type.

KASA Redberg
Engineers & Technicians



C_{fig} and Openings

KASA Redberg
Engineers & Technicians